Command:AHOME (AH)

MS2000 or RM2000 syntax

Shortcut	AH
Format	AH [X=fast_0] [Y=slow_0]
Units	Millimeters
Remembered	Using SS Z
Required Firmware Module	ARRAY MODULE

Tiger syntax

Shortcut	AH
Format	[addr#]AH [X=fast_0] [Y=slow_0]
Units	Millimeters
Type	Card-Addressed
Remembered	Using [addr#]SS Z
Required Firmware Module	ARRAY MODULE

Set the location of the first array position when using the ARRAY MODULE. The X setting is for the fast axis which is by default the X axis of the stage, but can be changed using the `SN Y` and `SN Z` settings (see SCAN command).

Without arguments, the command reads the current location and sets it to the first array position. When using arguments, `fast_0` and `slow_0` are coordinates expressed in millimeters.

commands, tiger, ms2000, array

From:
https://docs.asiimaging.com/ - **Applied Scientific Instrumentation**

Permanent link:
https://docs.asiimaging.com/commands/ahome?rev=1744848119

Last update: **2025/04/16 20:01**