

Command:ARM

Shortcut	ARM
Format	ARM [X] [Y=log] [Z]
Remembered	Using SS Z

Without arguments, this command establishes the **ARM_COMMAND_RCVD** event. Typically it is used to start the SEQUENCER via a single serial command.

ARM X re-initializes the SEQUENCER. This command is useful if the RESET conditions are changed or if the sequencer is hung in a non-IDLE state.

ARM Y=1 turns on or ARM Y=0 turns off the serial log file creation.

ARM Z forces a “sequence stop” condition. The sequencer is re-initialized; all blocks with ALWAYS start conditions are placed in the IDLE state, and all stage motion is halted.

[commands](#), [ms2000](#), [sequencer](#)

From:

<https://docs.asiimaging.com/> - **Applied Scientific Instrumentation**

Permanent link:

<https://docs.asiimaging.com/commands/arm?rev=1632431782>

Last update: **2021/09/23 17:16**

